




# Self-Installation Kit

## ZIP SOFT LANDING



The SELF INSTALLATION KIT is a simple and economical way to install and operate your own pneumatic tube system. Using our **Zip Soft Landing** stations on each end of the system, connected by Schedule 40 PVC piping, couplings, and bends; you have a complete working tube system at your service.

This SELF INSTALLATION KIT saves you the cost of installation and gives you the equipment you need to install it yourself. You get the pneumatic tube equipment shipped to your location for you or your own servicemen to perform the installation. You supply the schedule 40 PVC straight tubing, couplings, cleaner, glue and hanging material (available at nearly every hardware store) we supply the rest\*. It's that simple.

### Zip Pneumatics Supplies:


- 2 – Soft Landing Stations/blowers
- 2 (min) – Bends, 90 deg, 36" rad.
- 1 (min) - Carrier

### Local Hardware Store Supplies:

- Schedule 40 PVC Pipe and Couplings
- PVC Pipe Cleaner and Glue
- Hanger Material for Pipe

This **Zip Soft Landing** system has many different sizes of schedule 40 PVC to choose from: 3", 4", and 6" and comes with carriers (the capsules that hold the items) that are approximately  $\frac{3}{4}$ " smaller than the desired size of tubing (Ex: 4" carriers would have an outside diameter of 3  $\frac{1}{4}$ " to 3  $\frac{1}{2}$ " so it can fit through the tubing, leaving an inside diameter of about 3" for your items).

The **Zip Soft Landing** station is used when a facility requires minimal noise but still wants the advantages of a pneumatic tube system. The blower can be placed in a ceiling, cabinet, or any other closed space, and is attached to the station from beneath. By attaching the blower this way, this also provides a soft landing for the carrier when it arrives. The **Zip Basic** station, as shown to the right, is used for both *down receive stations* (the stations that receive a carrier from above). The only difference is that a remote blower hole is placed on the bottom of each station in order to correctly attach the blower. It is not a requirement to have the blower immediately below the station.



The **Zip Soft Landing** 3" and 4" stations are 7  $\frac{1}{2}$ " W x 7  $\frac{1}{2}$ " D x 26" L and weigh 38 lbs while the 6" station is 10" W x 10" D x 26" L and weighs 42 lbs. Each station requires minimal learning time and merely utilizes a pushbutton in order to send the carrier through the tube system. The **Zip Soft Landing** station uses a remote blower instead of a built-in blower to create the soft landing ability for the carrier. This system is good for any single level and/or multi-level transportation needs for a facility.

*\* We supply the bends to our clients to minimize problems with carriers travel.*