



4" Semi-automatic Parts List

Part #	Description
ES10-516	1/4" Inline Flow Control Valve
ES10-530	5/32" Orange Tubing
ES10-506	5/32" T x 10-32 male elbow
ES10-514	tube "Y", 5/32" tube
ES10-500	5/32" to 1/4" Plug in Reducer
ES10-503	1/4" Expander
ES10-511	1/4" Union
ES10-507	1/4" npt x 3/8" Straight Connector
ES12-902	MEAN WELL POWER SUPPLY 5/24 Vdc
ES13-754	Magnetic Sensor SPST (normally closed) - Station
ES13-755	1/8" x 1/4" magnet for Mag Sensors
ES13-751	Sensor Magnetic SPST HV Threaded (normally open) - diverter
ES13-232	ALARM BUZZER
ES13-452	Carrier in Send Sensor (T-OPTIC)
ES13-450	Optic; arrival (receive) sensor, turnaround sensor
ES13-554	Station Overload Optic
ES16-001	545 Keyed Lock
ES16-002	545 Key
ES16-003	Lock Ramp
ES13-950	Viewpad 10 Touch Screen Panel
ES14-405	Cable Adapter, 9pin to USB
ES15-001	Cable, control board to 9pin
ES14-851	Circuit control board
ES17-091	Cover, control board, smoke plexiglas
ES15-072	station landing pad
ES17-503	Ramp, 1/8" x 8" x 48" Natural Plastic
ES15-345	4" SLIDEGATE
ES19-002	4" Diverter Slide Ring
ES15-055	4" O-Ring Seal
ES17-828	4" diverter flex, 32"
ES10-526	1 1/6" x 6" SS CYLINDER w/BUMPERS
ES10-523	3/4" x 4.5" Bore Air Cylinder
ESS9170	Shifter cover
ES15-110	Shifter seal
ES91-009	7.5 hp, 400 cfm, regenerative blower
ES15-014	Red Round Pushbutton
ES15-015	Green Round Pushbutton
ES15-018	Yellow Round Pushbutton
ES15-080	Universal Door
ES15-816	Universal Door Handle Assembly
ES16-472	Door Gasket Per Ft. 1/4" x 1"
ES16-003	Door Handle Cam
ES15-013	4" Launch Arm
ES15-007	4" Ramped Landing Pad
ES15-006	4" Flat Landing Pad
ES13-233	SOLID STATE RELAY 25AMP 4-32DC, 48-660AC
ES12-602	Vacuum Motor/Blower, Current 8.2 amps, 2M192